

5 Maintenance

5.1 Dust Screen Maintenance




Chart 5.1 Dustproof net maintenance

Shown as above illustration: Take out snap joints in direction ①, remove the front panel in direction ②, draw out the Dustproof net as ③, clean the net. Put the net back after dry and clean as ④, Install the front panel as ⑤, buckle the panels as ⑥.

Suggestion: every 6-month a time or more to clear the product.

5.2 Chamber Maintenance

A. Shown as Chart 5.2, ① remove the front panel, ② take out the nozzle.

B. shut off outlet valve, open the inlet valve, as ③ shown, use a clean soft cotton cloth to clean the atomizing chamber and the surface of mist maker, then close the inlet and open outlet to drain off the water, repeat again till it is completely clean.

Suggestion: clean every 6-month




Chart 5.2 Illustration for chamber maintenance

5.3 Filter Change




Chart 5.3 Steps of changing filter

Before changing the filter, shut off the power and the inlet valve. Shown as chart 5.3, ① take off the plastic semi-ring on the pipe side and push out the pipe; ② take the filter away from the mounting clip; ③ take off the plastic semi-ring on the filter side, ④ remove the 1/4" Push-fit connector; ⑤ change a new filter; ⑥ ⑦ ⑧ ⑨ ⑩ are steps to fix the new filter back like the way above mentioned.

Mark: the softening resin filter is to demineralize hard water in case of incrustation scale (white powder) on the surface, the filter is suggested to be used for 3-6 months based on water quality and change for new one at least 6 months.